

This professional grade USB to serial RS232 or RS485/422 adapter easily adds a serial port to your desktop or laptop computer allowing connection of digital load cells with RS232 or RS422/RS485 communication interface. Serial outputs are automatically configured as additional COM ports.



## FEATURES

- Protection against static electricity and surges up to 15KV
- Supports Windows/ Linux and Mac OS Operating systems
- USB Plug and Play allows easy installation
- Directly connects your computer to a G4 digital load cell
- Supports up to 4 loadcells without the need for external power

## APPLICATIONS


- Computer connection of digital load cell using USB port
- Computer connection of digital junction box using USB port

## OPTIONS

- M8 or M12 to DB9 adapter for use with our multi-channel converter box (JBD)

## PART NUMBER

	M8		M12	
	RS232+CAN	RS485/422	RS232+CAN	RS485/422
Part Number	159.1 - M8	159.2 - M8	159.1 - M12	159.2 - M12
Pin no. 1	GND	GND	GND	GND
Pin no. 2	-	-	-	-
Pin no. 3	CANH	RX+	CANH	RX+
Pin no. 4	-	-	-	-
Pin no. 5	CANL	RX-	CANL	RX+
Pin no. 6	RXD	TX-	RXD	TX-
Pin no. 7	TXD	TX+	TXD	TX+
Pin no. 8	PWR+	PWER+	PWR+	PWER+



1.19.22 V2